







	Power Button		Up Button
	Enter Button		Down Button




To Turn On Unit

- Hit Power  to turn on.
- Wait until screen says “*Survey Mode*”

To Calibrate Unit

- When screen says “*Survey Mode*”, hit Power 
- Hit Down  to get “*Zero Cal*”
- Hit Enter 
- Attach Zero Filter. Hit Enter . Wait 60 seconds.

To Start Logging

- Hit Power  to get “*Data Log*”
- Hit Enter  to get “*Run Manual*”
- Hit Enter  to get “*Logging Data*”
- Don’t touch.

To Stop Logging

- Hit Power  to get “*Enter = Stop*”
- Hit Enter 

Notes

- Wait a few seconds between hitting buttons.
- The unit can only store **five** sets of data

Downloading Data and Charts for SidePak

1. With the Unit off, connect the unit to the USB cord.
2. Plug the USB cord into the computer.
3. Load WordPerfect and leave it running in the background.
4. Load the TSI Software
5. Turn on Unit.
6. Top Menu: **File > Receive.**
7. Hit the **Select All** button.
8. Hit the **Receive** Button
9. Wait until tests load.
10. Hit **OK** on the popup window.
11. Hit **Close** button.
12. Hit Control-G.
13. Change the Title and Subtitles.
14. Add a checkmark in the box(es) of the test data set(s) you want to graph.
15. Hit **OK** button.
16. The graph appears on the screen.
17. Top Menu: **File > Export > Copy Graph To Clipboard.**
18. Hit the **Copy as Bitmap** button.
19. Hit the **OK** button on the popup window.
20. Switch to Wordperfect.
21. Top menu: **Edit > Paste.**
22. Repeat Steps 12-21 for additional graphs.